

CLEAR™ INSTALLATION GUIDE

CLEARPROTECTS.COM



Follow these steps to install your new CLEAR $^{\mathtt{m}}$ screen protector.

1. Preparation and Cleaning - The first and most important step to your perfect install.

Wash and dry your hands - Remove dirt and oils.

2. Clean your Screen - Use the provided cleaning wipe to clean off the entire screen.




Next, wipe the screen with the microfiber cloth and then use the dust removal tape to eliminate any remaining dust particles.

(Do NOT touch the device screen once it's cleaned.)

3. Alignment - Perfect alignment can be achieved with these easy steps.



Hold the sides of the glass with your fingertips so the protective layer is facing down. Pull the green "START" sticker to remove the entire protective layer. Do not touch the adhesive side once the protective layer is removed.



4. Alignment - Slowly lower the uncovered adhesive side to your screen while carefully aligning it with the sides, bottom and home button of your device.

If it does not align perfectly, gently lift immediately and adjust until you are satisfied.

Once in place, lightly tap the center and slide your forefinger across the middle in the shape of a cross.